


# XT-17M-B - Time relay, delay-off, 16 A, 1 C/O Manual

#### Description

The XT-17M-B is a delay-off time relay, available in 6 different ranges and has 1 C/O contact. With the S-input it is possible to control the relay remotely.

# Layout



- Control input
- Supply indication (green LED)
- Time range setting 3.
- Supply terminals
- Output indication (red LED)
- Time setting
- Output contacts

# Technical information

12...240 VAC Supply voltage Supply terminals A1-A2 1 C/O contact Contacts Rated current 16 A / AC1 Inrush current 30 A  $\leq$  3 s Ambient temperature -20 °C...+55 °C




Wabtec Netherlands B.V. Darwinstraat 10 6718 XR Ede the Netherlands


+31 (0)88 600 4500 wnl\_salessupport@wabtec.com

www.morssmitt.com


#### **Function**

When energising the S-input the contact resets. After de-energising the S-input the selected time delay will start. The coil of the relay can be energised permanently






### Main time setting impulse / pause



The main time setting selects the maximum time range.


#### Fine time setting

The time setting is set within the range of the relevant model via the potentionmeter.




Example: It the model is 6 s...60 s, the time setting for 30 seconds is 50 %.

# Connection diagram



#### Connection



- Install and connect wiring according the identification on the terminals and connection diagram
- Do not reverse the polarity of the coil connection
- Relays can be mounted next to each other
- Warning! Never use silicon near the relays

#### Operation

- Before first operation; always apply voltage to supply and check correct operation
- Switching the load a few times before first use is advisable
- When the LED is green, coil voltage is indicated
- When the relay does not operate but coil voltage is present, coil polarity can be
- Warning: Do not use the relay in locations with flammable gas, as the arc generated by switching could ignite the gas

#### Maintenance

- If the relay does not operate correctly, check the presence of the coil voltage by using a multimeter
- If the relay does not work after inspection, replace the relay by a similar model